

# Radtec Racing Radiators Sierra Cosworth Intercooler

## Fitting Guide

1. Remove water radiator and fans along with old Intercooler.
2. Offer new Intercooler up in to existing silicon pipe positions and line up brackets with holes already in chassis (these are located just in front of radiator mounting positions).
3. Fit Ford original pin and rubber mounting (available through Radtec or Ford) in to locating holes.
4. Fit Intercooler on these rubber mountings (leave loose at this point)
5. Adjust Intercooler in to best position as to allow silicon to fit pipe work.
6. Refit radiator and fans as removed from car (obviously do not try and fit old Intercooler).
7. If everything lines up okay and you are satisfied with fit, tighten up all mountings and refill water system.
8. If you feel more should be added to this guide please call Radtec sales team on 01543 502525 as your input would be greatly appreciated.